


## LESSON 2

### **Thermal Conductivity of Materials:**

Thermal conductivity is basically an indicator of rate of flow of heat through a material. A higher value of thermal conductivity means that material is a good conductor of heat whereas a lower value means that material is a bad conductor of heat and will act as an insulator. Physical structure and density determine the value of thermal conductivity of a material. It is denoted by 'k' and is defined as rate of heat transfer through a unit thickness of the material per unit area and per unit temperature difference.

$$k = - \frac{Q_x}{A \left( \frac{dT}{dx} \right)} \quad (1)$$

**Solids:** Solids generally consist of free electrons and atoms bound in periodic arrangement called lattice. Thermal conductivity in solids is attributed to migration of free electrons and lattice vibrations. Therefore, thermal conductivity of a solid is the sum of electronic component and lattice vibration component. Thermal conductivity of pure metals is high and contribution of electronic component is significant as compared to that of lattice vibration component as shown in Figure 1. Thermal conductivity of an alloy of two metals is considerably lower than that of either of two metals. For example values of thermal conductivity of copper and Nickel are 401 W/(m- °K) and 91 W/(m- °K) respectively whereas thermal conductivity of constantan ( 55% copper and 45% Nickel) is only 23 W/(m- °K).



**Figure 1**

Arrangement of molecules in a material strongly affects the lattice component of thermal conductivity. Crystalline solid such as diamond has the highest value of thermal conductivity at room temperature. Thermal conductivity of solids generally decreases with increase in temperature.

**Fluids:** Solids generally have the highest value of thermal conductivity followed by liquids and gases on account of intermolecular spacing between the molecules. In solids molecules are closely packed, in liquids loosely packed and in gases very loosely packed. Thermal conductivity of gases increases with increase in temperature while that of liquids decreases with increase in temperature with glycerin and water being exceptions. Table 3 gives the values of thermal conductivity of different materials.

Table 3: Thermal Conductivity of Materials at Room Temperature

S. No.	Material	Conductivity, $k$ , W/(m-K)
1.	Diamond	2300
2.	Silver	429
3.	Copper	401
4.	Gold	317
5.	Aluminum	237
6.	Iron	80.2
7.	Glass	0.78
8.	Water	0.607
9.	Wood	0.17
10.	Air	0.026

### **Objectives of conduction analysis:**


The basic objective of conduction analysis is to determine the variation of temperature with respect to location and time throughout a body. The knowledge of temperature distribution within a body is required to determine heat transfer rate. Location of a point within a body, at which temperature is to be determined, is specified by choosing a suitable coordinate system amongst Cartesian coordinates, cylindrical coordinates or spherical coordinates. Temperature at a point is expressed as

- $T(x, y, z, t)$  in rectangular or Cartesian coordinates for parallelepiped bodies
- $T(r, \phi, z, t)$  in cylindrical coordinates for cylindrical bodies
- $T(r, \phi, \theta, t)$  in spherical coordinates for spherical bodies.

For any irregular shaped body, generally rectangular or Cartesian coordinates are used for conduction analysis.

**(a) General Heat Conduction Equation in Cartesian Coordinates:**

Consider flow of heat through a very small control volume oriented into three dimensional. The sides  $dx$ ,  $dy$  and  $dz$  are parallel to  $x$ ,  $y$  and  $z$  axes respectively as shown in Figure 2.



**Figure 2**

Let 'T' be the temperature of left face AEHD and it changes along x-direction. Let the temperature changes by amount  $\partial T$  through a unit distance  $\partial x$  and temperature gradient is expressed as  $\frac{\partial T}{\partial x}$ . Similarly, change of temperature through distance  $dx$  will

be  $\frac{\partial T}{\partial x} dx$  and temperature at the right face BFGC is  $(T + \frac{\partial T}{\partial x} dx)$ . For non-isotropic

materials, thermal conductivity changes as heat flows through the control volume. If  $K_x$  is

the thermal conductivity at the left face AEHD, then quantity of heat flowing in to the control volume along x-direction through left face during time interval dt is expressed as

$$Q_x = -k_x A \frac{\partial T}{\partial x} dt = -k_x dydz \frac{\partial T}{\partial x} dt \quad (2)$$

Where, A is the area of the left face ADHD

During same interval of time, heat flowing out of the right face BFGC along x-direction will be

$$Q_{x+dx} = Q_x + \frac{\partial(Q_x)}{\partial x} dx \quad (3)$$

Heat accumulated in the control volume due to flow of heat along x-direction will be

$$\begin{aligned} q_x &= Q_x - Q_{x+dx} = Q_x - \left( Q_x + \frac{\partial(Q_x)}{\partial x} dx \right) \\ &= - \left( \frac{\partial(Q_x)}{\partial x} dx \right) = - \frac{\partial}{\partial x} \left( -k_x dydz \frac{\partial T}{\partial x} dt \right) dx \end{aligned} \quad (4)$$

$$= \frac{\partial}{\partial x} \left( k_x \frac{\partial T}{\partial x} \right) dx dy dz dt \quad (5)$$

Similarly, heat accumulated in the control volume due to heat flow along y and z directions can be expressed as

$$q_y = \frac{\partial}{\partial y} \left( k_y \frac{\partial T}{\partial y} \right) dx dy dz dt \quad (6)$$

$$q_z = \frac{\partial}{\partial z} \left( k_z \frac{\partial T}{\partial z} \right) dx dy dz dt \quad (7)$$

Let there is a heat source present inside the control volume which is generating 'q<sub>g</sub>' amount of heat per unit volume per unit time. Total heat generated in the control volume can be expressed as

$$= q_g dx dy dz dt \quad (8)$$

Total heat accumulated in the control volume is the sum of equations (5), (6), (7) and (8) and it results in increase in the thermal energy of the control volume. This increase in

thermal energy is reflected by rate of change of heat capacity of the control volume during given time interval 'dt' and is expressed as

$$\begin{aligned}
 &= \text{Mass of the control volume} \times \text{specific heat} \times \text{change of temperature of control} \\
 &\quad \text{volume per unit time} \times \text{Time interval} \\
 &= \rho(dx dy dz) C \frac{\partial T}{\partial t} dt \tag{9}
 \end{aligned}$$

Heat Capacity or thermal capacity is defined as heat required to raise temperature of whole mass of a body by 1°C and is expressed as

$$= \text{mass of a body} \times \text{specific heat}$$

From energy balance considerations, sum of equations (5), (6), (7) and (8) should be equal to equation (9).

$$(dx dy dz dt) \left[ \frac{\partial}{\partial x} \left( k_x \frac{\partial T}{\partial x} \right) + \frac{\partial}{\partial y} \left( k_y \frac{\partial T}{\partial y} \right) + \frac{\partial}{\partial z} \left( k_z \frac{\partial T}{\partial z} \right) + q_g \right] = \rho(dx dy dz) C \frac{\partial T}{\partial t} dt \tag{10}$$

$$\left[ \frac{\partial}{\partial x} \left( k_x \frac{\partial T}{\partial x} \right) + \frac{\partial}{\partial y} \left( k_y \frac{\partial T}{\partial y} \right) + \frac{\partial}{\partial z} \left( k_z \frac{\partial T}{\partial z} \right) + q_g \right] = \rho C \frac{\partial T}{\partial t} \tag{11}$$

Equation (11) represents general conduction equation for three dimensional, unsteady heat flow through a non-isotropic material.

For homogeneous and isotropic materials,  $k_x = k_y = k_z = k$ . Therefore, Equation (11) will become

$$\frac{\partial^2 T}{\partial x^2} + \frac{\partial^2 T}{\partial y^2} + \frac{\partial^2 T}{\partial z^2} + \frac{q_g}{k} = \frac{\rho C}{k} \frac{\partial T}{\partial t} \tag{12}$$

$$\frac{\partial^2 T}{\partial x^2} + \frac{\partial^2 T}{\partial y^2} + \frac{\partial^2 T}{\partial z^2} + \frac{q_g}{k} = \frac{1}{\alpha} \frac{\partial T}{\partial t} \tag{13}$$

Where,  $\alpha = \frac{k}{\rho C}$  and is called thermal diffusivity of a material and it represents how quickly heat will propagate through a material. Thermal diffusivity is defined as ratio of heat conducted by a material to the heat stored by it per unit volume.

$$\alpha = \frac{\text{Heat Conducted}}{\text{Heat Stored}}, \text{ m}^2/\text{sec}$$

Heat will propagate more quickly in a material having higher value of thermal diffusivity and materials with smaller thermal diffusivity will store most of the heat.

Equation (13) is known as **Fourier-Biot equation** and can be written as

$$\Delta^2 T + \frac{q_g}{k} = \frac{1}{\alpha} \frac{\partial T}{\partial t} \quad (14)$$

$\Delta^2$  is called Laplacian operator.

Different Cases:

- i) If flow of heat is under unsteady state conditions and no heat generation within the control volume takes place, then  $q_g = 0$  and Equation (13) can be written as

$$\frac{\partial^2 T}{\partial x^2} + \frac{\partial^2 T}{\partial y^2} + \frac{\partial^2 T}{\partial z^2} = \frac{1}{\alpha} \frac{\partial T}{\partial t} \quad (15)$$

Equation (15) is known as **diffusion equation**

- ii) If flow of heat is under steady state conditions, then temperature will not change with time and  $\frac{\partial T}{\partial t} = 0$ . Equation (13) can be written as

$$\frac{\partial^2 T}{\partial x^2} + \frac{\partial^2 T}{\partial y^2} + \frac{\partial^2 T}{\partial z^2} + \frac{q_g}{k} = 0 \quad (16)$$

Equation (16) is known as **Poisson equation**

- iii) If flow of heat is under steady state conditions without heat generation, Equation (13) can be written as

$$\frac{\partial^2 T}{\partial x^2} + \frac{\partial^2 T}{\partial y^2} + \frac{\partial^2 T}{\partial z^2} = 0 \quad (17)$$


Equation (17) is known as **Laplace equation**

- iv) For steady state and one-dimensional flow of heat through a body in which there is no heat generation, then Equation (13) can be written as

$$\frac{\partial^2 T}{\partial x^2} = 0 \quad (18)$$

**(b) General Heat Conduction Equation in Cylindrical Coordinates:**

When conductive heat transfer occurs through bodies having cylindrical geometries such as rods, pipes etc., general conduction equation is derived in cylindrical coordinates. Let us consider a control volume having cylindrical dimensions  $(r, \phi, z)$  and  $dr, dz$  and  $r d\phi$  are the three sides of the control volume as shown in Figure 3.



**Figure 3**

Heat inflow through  $(r, z)$  plane along  $\phi$  direction is expressed as

$$Q_{\phi} = -k dr dz \frac{\partial T}{r \partial \phi} dt \quad (19)$$

Heat outflow through  $(r, z)$  plane along  $\phi$  direction is expressed as

$$Q_{\phi+d\phi} = Q_{\phi} + \frac{\partial(Q_{\phi})}{r \partial \phi} r d\phi = -k dr dz \frac{\partial T}{r \partial \phi} dt + \frac{\partial \left( -k dr dz \frac{\partial T}{r \partial \phi} dt \right)}{r \partial \phi} r d\phi \quad (20)$$

Heat accumulated in control volume due to flow through  $(r-z)$  plane during time interval  $dt$  is expressed as

$$q_{\phi} = Q_{\phi} - Q_{\phi+d\phi} = k dr dz d\phi \frac{\partial}{\partial \phi} \left( \frac{1}{r} \frac{\partial T}{\partial \phi} \right) dt \quad (21)$$

Heat inflow through  $(r, \phi)$  plane along z-direction is expressed as

$$Q_z = -k r d\phi dr \frac{\partial T}{\partial z} dt \quad (22)$$

Heat outflow through  $(r, \phi)$  plane along z-direction is expressed as

$$Q_{z+dz} = Q_z + \frac{\partial(Q_z)}{\partial z} dz = -k r r dr d\phi \frac{\partial T}{\partial z} dt + \frac{\partial \left( -k r r dr d\phi \frac{\partial T}{\partial z} dt \right)}{\partial z} dz \quad (23)$$

Heat accumulated in control volume due to flow through  $(r- \phi)$  plane during time interval 'dt' is expressed as

$$q_z = Q_z - Q_{z+dz} = k r d\phi dr dz \frac{\partial}{\partial z} \left( \frac{\partial T}{\partial z} \right) dt \quad (24)$$

Heat inflow through  $(z- \phi)$  plane along r-direction is expressed as

$$Q_r = -k dz r d\phi \frac{\partial T}{\partial r} dt \quad (25)$$

Heat outflow through  $(z- \phi)$  plane along r-direction is expressed as

$$Q_{r+dr} = Q_r + \frac{\partial(Q_r)}{\partial r} dr = -k r d\phi dz \frac{\partial T}{\partial r} dt + \frac{\partial \left( -k r d\phi dz \frac{\partial T}{\partial r} dt \right)}{\partial r} dr \quad (26)$$

Heat accumulated in control volume due to flow through  $(z- \phi)$  plane during time interval dt is expressed as

$$q_r = Q_r - Q_{r+dr} = k d\phi dr dz \frac{\partial}{\partial r} \left( r \frac{\partial T}{\partial r} \right) dt \quad (27)$$

Let there is a heat source present inside the control volume which is generating  $q_g$  amount of heat per unit volume per unit time. Total heat generated in the control volume can be expressed as

$$= q_g r d\phi dr dz dt \quad (28)$$

Total heat accumulate in the control volume is the sum of equations (21), (24), (27) and (28) and it results in increase in the thermal energy of the control volume. This increase



in thermal energy is reflected by rate of change of heat capacity of the control volume during given time interval 'dt' and is expressed as

$$= \rho (rd\phi dr dz) C \frac{\partial T}{\partial t} dt \quad (29)$$

From energy balance considerations, sum of equations (21), (24), (27) and (28) should be equal to equation (29).

$$(kd\phi dr dz dt) \left[ \frac{1}{r} \left( \frac{\partial^2 T}{\partial \phi^2} \right) + \frac{\partial}{\partial r} \left( r \frac{\partial T}{\partial r} \right) + r \frac{\partial^2 T}{\partial z^2} + \frac{q_g r}{k} \right] = \rho (rd\phi dr dz) C \frac{\partial T}{\partial t} dt \quad (30)$$

$$\left[ \frac{1}{r} \left( \frac{\partial^2 T}{\partial \phi^2} \right) + r \frac{\partial^2 T}{\partial r^2} + \frac{\partial T}{\partial r} + r \frac{\partial^2 T}{\partial z^2} + \frac{q_g r}{k} \right] = \frac{\rho C}{k} r \frac{\partial T}{\partial t} \quad (31)$$

Replacing  $\frac{\rho C}{k} = \alpha$  in Equation (31)

$$\left[ \frac{1}{r^2} \left( \frac{\partial^2 T}{\partial \phi^2} \right) + \frac{\partial^2 T}{\partial r^2} + \frac{1}{r} \frac{\partial T}{\partial r} + \frac{\partial^2 T}{\partial z^2} + \frac{q_g}{k} \right] = \frac{1}{\alpha} \frac{\partial T}{\partial t} \quad (32)$$

Equation (32) represents general conduction equation for three dimensional, unsteady heat flow in cylindrical coordinates.

### (C) General Heat Conduction Equation in Spherical Coordinates:

Similarly, the general conduction equation for geometries having spherical coordinates can be obtained and is expressed as:

$$\left[ \frac{\partial^2 T}{\partial r^2} + \frac{2}{r} \frac{\partial T}{\partial r} + \frac{1}{r^2 \sin^2 \theta} \left( \frac{\partial^2 T}{\partial \phi^2} \right) + \frac{1}{r^2 \sin \theta} \frac{\partial}{\partial \theta} \left( \sin \theta \frac{\partial T}{\partial \theta} \right) + \frac{q_g}{k} \right] = \frac{1}{\alpha} \frac{\partial T}{\partial t} dt \quad (33)$$

### REVIEW QUESTIONS:

Q.1 Unit of thermal conductivity in S.I. units is

- |                             |                      |
|-----------------------------|----------------------|
| a) J/m <sup>2</sup> sec     | b) J/m °K sec        |
| c) W/m °K                   | d) (a) and (c) above |
| <b>e) (b) and (c) above</b> |                      |

- Q.2 Thermal conductivity of solid metals with rise in temperature normally
- a) increases
  - b) decreases**
  - c) remains constant
  - d) may increase or decrease depending on temperature
  - e) unpredictable

Q.3 Thermal conductivity of non-metallic amorphous solids with decrease in temperature

- a) increases
- b) decreases**
- c) remains constant
- d) may increase or decrease depending on temperature
- e) unpredictable

Q.4 Thermal diffusivity of a substance is

- a) proportional of thermal conductivity (k)**
- b) inversely proportional to k
- c) proportional to  $(k)^2$
- d) inversely proportional to  $k^2$
- e) none of the above

Q.5 Fourier's law of heat conduction is valid for

- a) one dimensional cases only**
- b) two dimensional cases only
- c) three dimensional cases only
- d) regular surfaces having non-uniform temperature gradients
- e) irregular surfaces

Q.6 The heat transfer equation  $\frac{\partial^2 t}{\partial x^2} + \frac{\partial^2 t}{\partial y^2} + \frac{\partial^2 t}{\partial z^2} = 0$  is known as

- a) Laplace's equation**
- b) Stefan-Boltzmann equation
- c) Fourier equation
- d) Poisson's equation
- e) General equation of heat transfer